POLY-TUFF SYSTEMS INTERNATIONAL

2250 E. Tropicana Ave Suite 19-600 Las Vegas, NV 89119



Phone: (866) 977-8833 Fax: (800) 804-0182 Email: sales@polytuffus.com Web: www.polytuffus.com



10/2/2006

Plywood Joint Preparation for Non-Metal Lath Walking Decks

- Caulk all plywood joint junctures with single or two component urethane and allow to dry. P-Tuff Flex, P-Tuff 100 or P-Tuff Classic may be used with Thixo to seal joints if preferred for fast curing.
- Press sealant or coating into the joint by using a margin trowel.
- Apply a thin coat, approximately 20 mils thickness over the sealant.
- Press 3-4" wide polyester or yellow jacket tape into the wet sealant or coating.
- Apply base coat as specified in related Flexideck System Data Sheet

The systems are outlined in the Flexideck Systems in the Poly-Tuff Binder or at www.polytuffus.com. Consult the related data sheet or call 866.977.8833 for further information.

Bob Clanton

Bob Clanton National Sales Manager 702.343.7067